

# Water Testing Best Practices

Marianne R. Metzger

National Testing Laboratories, Ltd.

2016 Pacific Water Quality Association Conference



# Know your regulations

- ▶ Do you need Certified Analysis?
  - ▶ Are results going to be sent to a regulatory agency?
    - ▶ What regulations are you trying to meet?
      - ▶ Safe Drinking Water Act
      - ▶ Clean Drinking Water Act
      - ▶ FHA/VA or HUD
    - ▶ Are results potentially going to be used in litigation?
- ▶ Informational Testing
  - ▶ Needed to determine treatment options
  - ▶ Troubleshooting



# Laboratory certification

- ▶ EPA Certification
  - ▶ Cryptosporidium
  - ▶ UCMR
- ▶ State Certification
  - ▶ Direct
  - ▶ Reciprocal
- ▶ NELAP Accreditation
  - ▶ 14 States
- ▶ ISO Accreditation
  - ▶ International Organization for Standardization
- ▶ Categories of Certification
  - ▶ Safe Drinking Water Act
  - ▶ Clean Water Act
  - ▶ Clean Air Act
  - ▶ Underground Storage Tanks
  - ▶ Resource Conservation and Recovery Program



# Certification requirements

- ▶ Time Commitment
  - ▶ Labs that have never been certified takes 12-18 months
- ▶ Written Laboratory Quality Manual
- ▶ Onsite Inspection
- ▶ Proficiency Testing
  - ▶ Performance Evaluation Samples
  - ▶ Initially performed to show analyst capability of providing accurate results for each method/analyte
  - ▶ Ongoing testing to maintain certification
- ▶ Payment of Fees



# Approved methods

- ▶ Environmental Protection Agency (EPA)
- ▶ Standard Methods
- ▶ American Society for Testing and Materials
- ▶ United States Geological Survey
- ▶ Resource for method information
  - ▶ [www.nemi.gov](http://www.nemi.gov)

A dark grey arrow points to the right at the top left. Below it, several thin, curved lines in shades of blue and grey sweep across the left side of the slide.

# Chain of Custody


- ▶ Definition

- ▶ Chronological record of who has been in possession of the samples and what analyses have been performed on them.

- ▶ Guidelines

- ▶ Keep number of people handling samples and data to a minimum.
- ▶ Always document the transfer of samples or data from one person to another.
- ▶ Give samples and data positive identification at all times that is legible and written with permanent ink.

# Example of Chain of Custody

CLIENT/COMPANY NAME:			S A M P L E  T Y P E	# O F C O N T A I N E R S	TEST(S) REQUESTED PER SAMPLE (X)												LAB #			
CLIENT COMMENTS:		TYPES OF SAMPLES: 			/ / / / / / / / / / / / / / / /															
TIME SAMPLE #	COLLECTION																	SAMPLE SITE DESCRIPTION		
	DATE																			
RECEIVER SIGNATURE CONFIRMS THAT THE BOTTLES RECEIVED ARE CONSISTENT WITH THE REQUIRED TESTING PROTOCOL.				RELINQUISHED BY: (Signature) (4)					LABORATORY COMMENTS:											
SAMPLED BY: (Signature) (1)				RECEIVED BY: (Signature) (5)																
SHIPPED BY: (Signature) (2)				RELINQUISHED BY: (Signature) (6)																
RECEIVED BY: (Signature) (3)				RECEIVED BY: (Signature) (7)																



# What to test

- ▶ Microbiological
  - ▶ Bacteria
  - ▶ Parasites
  - ▶ Viruses
- ▶ Inorganics
  - ▶ Metals/Minerals
  - ▶ Compounds : nitrates, nitrite, chlorides, fluorides, sulfates
- ▶ Volatile Organics
- ▶ Semi-Volatile Organics
- ▶ Radiologicals



A decorative graphic on the left side of the slide. It features a dark blue vertical bar on the far left. A black arrow points to the right from the top of this bar. Several thin, curved lines in shades of blue and grey originate from the bottom left and sweep upwards and to the right, crossing the main content area.

# Proper Sample Collection

- ▶ Sampling Containers
  - ▶ Glass
  - ▶ Plastic
  - ▶ Amber
- ▶ Size of sampling containers
  - ▶ Enough water to run analysis
  - ▶ Regulation driven
- ▶ Preservation
  - ▶ Temperature protection
  - ▶ Chemical
    - ▶ Dechlorination
    - ▶ Acidification
- ▶ Holding times

A dark blue arrow points to the right from the left edge of the slide. Several thin, curved lines in shades of blue and grey originate from the left side and sweep across the slide, framing the text.

# What to test for? What does your client need?

- ▶ Certified/Compliance Testing
  - ▶ Regulations will dictate what is required
- ▶ Informational Testing
  - ▶ Diagnosis Treatment Needs
  - ▶ Address client's health concerns
  - ▶ Testing after to equipment to show client water improvement



# Where to test

- ▶ Pre/Post Treatment
  - ▶ Raw Water
  - ▶ Troubleshooting
- ▶ Regulation Driven
  - ▶ PWTA
  - ▶ Public Water Supplies
    - ▶ Lead and Copper Rule
    - ▶ THM/HAA
- ▶ QAPP Quality Assurance Project Plan
  - ▶ written document that provides a blueprint for the entire project and each specific task to ensure that the project produces reliable data that can be used to meet the project's overall objectives and goals.

# Microbiological Testing

- ▶ Which sink is better for sampling?



# Microbiological Testing

- Remove Aerator/Screen other devices attached to faucets
- Disinfect Faucet
  - Isopropyl Alcohol
  - Flame
  - Chlorine
- Only Use Sterilized Bottles
  - Do not use if seal is broken
- Take Care not to Contaminate Your Sample
  - Do not touch inside bottle or cap
  - Do not set the cap down
- Fill the bottle to appropriate Fill Line
- Preservation
  - Sodium Thiosulfate needed for chlorinated source
  - Samples should arrive at the lab at  $\leq 10^{\circ}\text{C}$
- Short Holding Times
  - Regulation dependent
  - 6 Hours – 30 hours





# Metals Analysis

- ▶ What is the purpose of the testing?
  - ▶ Lead and Copper Rule
  - ▶ Lead/Copper Concerns
- ▶ To remove the Aerator or Not?
- ▶ Plastic Bottles
- ▶ Preservation
  - ▶ Acidification
- ▶ Holding Times
  - ▶ 14 days with acidification
  - ▶ 6 months once acidified




# Other Inorganic testing

- ▶ Common Inorganics
  - ▶ Nitrate, Nitrite, Chloride, Fluoride, Sulfate, Bromate, Bromide, Chlorate, ortho-phosphate
- ▶ Various Bottle Requirements
- ▶ Preservation
  - ▶ None
  - ▶ Samples should arrive at the lab between 2 – 6 °C
    - ▶ Nitrate, nitrite, ortho-phosphate and sulfate
  - ▶ Ethylenediamine (EDA)
    - ▶ Bromate, chlorate, and chlorite
- ▶ Holding Times
  - ▶ 48 hours – nitrate, nitrite & phosphate
  - ▶ 14 days – chlorite
  - ▶ 28 days – chloride, fluoride, sulfate, bromate, bromide & chlorate

# VOCs

## Volatile Organic Compounds

- ▶ Sample Collection Vials
  - ▶ 40 ml Vials
  - ▶ Teflon lined Septum
- ▶ Headspace
  - ▶ Slightly overfill forming a meniscus
  - ▶ No air bubbles
- ▶ Preservation
  - ▶ Sodium Thiosulfate/Ascorbic Acid
  - ▶ Hydrochloric – Field Acidification
- ▶ Holding Times
- ▶ Trip Blanks





A dark blue arrow points to the right from the left edge of the slide. Several thin, curved lines in shades of blue and grey originate from the left side and sweep across the slide towards the right.

# Semi-Volatiles

- ▶ Organic compounds that volatilize slowly at standard temperature
- ▶ Sample Bottles
  - ▶ Varies based on method
  - ▶ Glass
  - ▶ Amber Glass
- ▶ Preservatives
  - ▶ Misc
  - ▶ Hydrochloric Acid
- ▶ Holding Times
  - ▶ Extraction
  - ▶ Runs



# Radiologicals



- ▶ Gross Alpha & Beta, Radium 226 & 228, Strontium-90
- ▶ Sample Bottles
  - ▶ Plastic
  - ▶ Volume based upon test
- ▶ Preservation
  - ▶ Acidification within 14 days of collection
- ▶ Holding Times
  - ▶ Based upon half life of radiological

A dark blue arrow points to the right at the top left. Below it, several thin, curved lines in shades of blue and grey sweep across the left side of the slide.

# Testing best practices

- ▶ Determine if tests need to be certified or if informational is applicable
- ▶ Determine what needs to be tested
- ▶ Order Bottles from Laboratory
- ▶ Review Laboratory Instructions for proper sampling before going to collect the sample
  - ▶ Confirm you have everything you need to collect sample
- ▶ Collect samples according to procedures provided
- ▶ Deliver or ship samples to the lab
  - ▶ Ensure samples will arrive at the lab within proper holding time
  - ▶ Ensure sample to arrive within proper temperature.



# Questions?

Thank you for attending  
Marianne R. Metzger  
National Testing Laboratories, Ltd.